

Select Settings on the F4T Home Screen



Then select Network



Select Ethernet



Change IP address Mode to DHCP

Then save settings

